

Teco S300



??????: ??? ???????
????:

[?????? ?????? ?? ????? ??????](#)

?????????????: [Teco](#)

?????????

RFID- ??????? ?????????????? ????????? ??????? ?????? ?????????? ????????

?????????

4-? ????????? ??????, 16 ??????, 40000 ???????
????????????? ? ?????? ??????

????????? Linux, ?????? ?????? ?????????? ? ???????
????????? ?????? ?????? U-????
????????????? ?????? ???? ?????????????? ?????????? ? ?????????????? ? ?????????????? ??????
????????????????????? ?????????? ?????????? ?????????? ?????????? ?????????? ?????????? ??????????, ?????????? ?????????????????? ?????????????.

CPU:32 bit
????????????? ?????????? TCP/IP
USB-HOST,CLIENT
????????????? ??????????????????

????????????? ??????????????????
????????????? ??????????????????:30000/50000
????????????? ??????????:50000/80000
U-?????:128M(????????????? ?????????????? USB 2.0)
?????????????:ZEM300
????????? ??????: PSK 125 KHz
????????????? ?????????? ??????: 2-22cm
?????????????????????:5VDC,2?
????????????? ??????????: TCP/IP;RS485;RS232
?????? ??????????????????: ?20ms
?????????????: 16 ?????? ? ??????????????
LED:2 ?????????? ?????????????? (????????? ? ??????????)
LCD:128x64
????????? ?????????? ??????????????:-20?-70?
????????? ?????????? ??????????????:20%-80%
?????????: 180*125*55 mm
?????????????: ?????????? ???, ?????????????????????? ??????????, ??????????????
?????: ?????????? ??????????, ??????????, ?????? HID, Mifare

??????
??? ?????????? ?? ?????? ???????.